

Product: Current Datalogic ADC Mobile Devices




Distribution Date: 5 July, 2012

How to install PAL Communicator


This document provides step-by-step instructions on how to install the PAL Communicator software on a PC, allowing communications to the PAL software program for all current Datalogic Mobile devices. Please note that your screen appearance may vary slightly.

- 1) Download the PAL Communicator software by clicking on the link to the right and saving it to your desktop.
- 2) Unzip the file and save the embedded files on the desktop.


Link: [PAL Communicator Software](#)




- 3) Browse to the desktop where the unzipped files were saved and run the setup.exe file.




- 4) Click on the NEXT button to proceed with the installation.




- 5) Allow the default path of:
C:\ProgramFiles\Datalogic\Pal
Communicator\ and select NEXT




- 6) Click NEXT.




- 7) The installation process will proceed as directed.



- 8) Select the CLOSE button when INSTALLATION COMPLETE displays.



- 1) To open PAL Communicator, select START → PROGRAMS → DATALOGIC → PAL COMMUNICATOR.



PAL Communicator is now installed on the PC and ready to use.

References

- 2) [PAL and PAL Communicator Datasheet](#)
- 3) [PAL Win Manual](#)

For additional assistance, please contact your local [Technical Support](#).

Additional information is available on www.adc.datalogic.com.